



Drill Sequence

3.3mmD Straight / Tapered Implant

3.3/3.7



2.3mmD Drill



SOFT BONE
3.3mmD Implant

DENSE BONE
3.3mmD Implant



SPD2.8



Use SPD2.8 Drill as final step for Tissue-level or Bone-level placement
Crestal bone in Maxilla will expand without countersink




Tissue Level
FINAL DRILL
SPCD3.3
3.3mmD/3.7mmD



Bone Level
FINAL DRILL
SPCD3.3
3.3mmD/3.7mmD

4.1mmD Straight / Tapered Implant

4.1/4.8



2.3mmD Drill



SOFT BONE
4.1mmD Implant

DENSE BONE
4.1mmD Implant



SPD2.8




SPD3.5



Use SPD3.5 Drill as final step for Tissue-level or Bone-level placement
Crestal bone in Maxilla will expand without countersink



Tissue Level
FINAL DRILL
SPCD4.1
4.1mmD/4.8mmD



Bone Level
FINAL DRILL
SPCD4.1
4.1mmD/4.8mmD

4.8mmD Straight / Tapered Implant

4.8/4.8

4.8/6.5



2.3mmD Drill



SOFT BONE
4.8mmD Implant

DENSE BONE
4.8mmD Implant



SPD2.8



SPD3.5



SPD4.2



Use SPD4.2 Drill as final step for Tissue-level or Bone-level placement
Crestal bone in Maxilla will expand without countersink



Tissue Level
FINAL DRILL
SPCD4.8
4.8mmD/4.8mmD




Bone Level
FINAL DRILL
SPCD4.8
4.8mmD/4.8mmD

Use SPD4.2 Drill as final step for Tissue-level placement.
Crestal bone in Maxilla will partially expand to allow 1mm subcrestal seating of neck.



Tissue Level
FINAL DRILL
SPCD4-6
4.8mmD/6.5mmD



Bone Level
FINAL DRILL
SPCD4-6
4.8mmD/6.5mmD

5.7mmD Straight / Tapered Implant

5.7/6.5



D2.3
2.3mmD Drill



SOFT BONE
5.7mmD Implant

DENSE BONE
5.7mmD Implant



SPD2.8



SPD3.5



SPD4.2



SPD5.1



Use SPD5.1 Drill as final step for Tissue-level or Bone-level placement
Crestal bone in Maxilla will expand without countersink



Tissue Level
FINAL DRILL
SPCD5-6
5.7mmD/6.5mmD



Bone Level
FINAL DRILL
SPCD5-6
5.7mmD/6.5mmD